




Disney

43176




6310700 **⚠ WARNING: CHOKING HAZARD.**
Small parts. Not for children under 3 years.


1




2







3



4



Disney PRINCESS



LEGO.com/service

LEGO.com/disney

⚠ **AVERTISSEMENT : RISQUE D'ÉTOUFFEMENT.**
 Contient des petites pièces. Ne convient pas aux enfants de moins de 3 ans.
 ⚠ **ADVERTENCIA: PELIGRO DE ASFIXIA.**
 No recomendado para niños menores de 3 años. Contiene piezas pequeñas.