




# Friends™

41441




































































































































































1x  
6226644



1x  
6301315



1x  
6174193



1x  
6253681



1x  
6276993



1x  
6344389



1x  
6096109



1x  
249626



6x  
4568644



1x  
300326



1x  
6273226



1x  
302126



1x  
6199275



1x  
6338416



1x  
6102360



2x  
6291040



1x  
4211190



1x  
6270119




1x  
4621545



1x  
6160819



2x  
6097094



1x  
6097710



3x  
6286831



1x  
4187743



1x  
6133836



2x  
6133225



2x  
6152645



1x  
6356469



1x  
6139090



1x  
6107188



1x  
4651902




1x  
4655173




5x  
6269015



1x  
6347555



1x  
6343444



1x  
6343443



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



00800 5346 5555 :



1-800-422-5346 :

